



## Lowering Alkalinity/PH in Pools

1. Turn the Pool Pump off
2. When the water is still, pour PH Reducer (Down) or Lo 'N Slow PH Decreaser or Muriatic Acid into **the deep end of the pool**
3. Turn the pool pump on after 1 hour
4. It may take several days to adjust
5. When Alkalinity is balanced then balance PH

*Note: Failure to balance the alkalinity in a pool could result in permanent wrinkling of the liner and corrosion of the pool pump and the heater equipment*